Wireless Keyboard | NS-PNK5011/NS-PNK5011-C

INSIGNIA


Package contents


- · Wireless keyboard
- Nano receiver
- AAA alkaline batteries (2)
- Quick Setup Guide

System requirements

- Windows® 8, Windows® 7, Windows Vista®, Windows® XP, or Mac OS 10.X or higher
- One available USB port

Keyboard features






#	lcon	Function	Description
1	▶/	Play/Pause	Press to play or pause media.
2		Stop	Press to stop playing media.
3	4	Previous	Press to select the previous media track.
4	₹	Next	Press to select the next media track.
5	4	Volume down	Press to decrease the computer's volume.
6	4 +	Volume up	Press to increase the computer's volume.
7	Ж	Mute	Press to turn off your computer's sound.
8		Calculator	Press to start Microsoft calculator.
9	LED indicator		Low battery and pairing indicator. See "LED indicator" for more information.
10	Connect button		Press to initiate pairing with your computer.
11	Battery cover		Remove to install or replace the batteries.


Installing the keyboard batteries

- **1** Take the battery cover off.
- 2 Insert two AAA batteries (included) into the battery compartment. Make sure that the + and - signs match the symbols in the compartment.
- **3** Replace the cover.



Setting up the connection between the nano receiver and keyboard


- 1 Plug the nano receiver into the USB port on your computer.
- **2** The computer automatically detects your keyboard and you can immediately begin using it.



If the keyboard does not work:

- · Move your computer and keyboard closer together.
- Re-plug the nano receiver into the USB port on your computer, then press
 the connect button on the keyboard. The LED indicator on the keyboard
 flashes steadily while in pairing mode (10 seconds). After pairing
 successfully, the LED indicator lights solid for 10 seconds, then turns off.
- Check the batteries in your keyboard. The LED indicator blinks for 10 seconds when the batteries are low.

LED indicator



Function	Description
Power ON	Red LED is on for 10 seconds, then turns off.
Low battery warning	Red LED blinks for 10 seconds.
Pairing	Red LED blinks for 10 seconds after pressing the Connect button.
Pairing failed	After pressing the Connect button, the LED blinks for 10 seconds, then turns off.
Paired successfully	After pressing the Connect button, the LED blinks, then lights solid for 10 seconds.

Cleaning your keyboard

• Wipe the keyboard with a damp, lint-free cloth.

Specifications

Keyboard:

• Dimension (L×W×H): $17.1 \times 5.6 \times .8$ in. $(43.4 \times 14.3 \times 2.06$ cm)

Weight: 16.9 oz. (.5 kg)Radio frequency: 2.4Ghz

• Operating distance: 33 feet (10 meters)

• Key number: 104 keys (US)

• Battery: 2 × AAA alkaline batteries

• Battery life: 6 months (based on average usage)

Nano receiver:

• Dimension (L×W×H): .7 x .6 x .2 in. (1.8 × 1.4 × .6 cm)

Weight: .04 oz. (.001 kg)Interface: USB 1.1, 2.0, 3.0

Troubleshooting

My keyboard is not working.

- · Move your keyboard closer to your computer.
- Make sure that your computer meets the system requirements.
- If your keyboard stops working:
- Make sure that your keyboard and nano receiver are paired by pressing the connect button on the keyboard.
- Replace the keyboard batteries.
- Try connecting your nano receiver into a different USB port on your computer.

Legal notices

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- · Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RSS-Gen and RSS-210 statement

This device complies with Industry Canada license-exempt RSS standard(s).

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

RSS-102 statement

This equipment complies with Industry Canada radiation exposure limits set forth for an uncontrolled environment.

Cet équipement est conforme à l'exposition aux rayonnements Industry Canada limites établies pour un environnement non contrôlé.

One-year limited warranty

For complete warranty, visit <u>www.insigniaproducts.com</u>.

Contact Insignia

1-877-467-4289 (U.S. and Canada) or 01-800-926-3000 (Mexico) www.insigniaproducts.com

INSIGNIA is a trademark of Best Buy and its affiliated companies. Registered in some countries. Distributed by Best Buy Purchasing, LLC 7601 Penn Ave South, Richfield, MN 55423 U.S.A. ©2014 Best Buy, All rights reserved. Made in China